# TruLaser 1000 Basic Edition (L99)

Economic reliable machine





### Easy to use and program

Control and programming are developed by TRUMPF and ensure a fast start for your production, even without a lot of know-how, thanks to numerous cutting parameters for the entire sheet thickness range.



#### Reliable machine and safe cutting

The machine is built at the same production line as all the other TRUMPF 2D-Laser machines. As with all our machines, it is safe during operation, thanks to enclosed protective housing and high-class laser safety window.



### High cutting performance

High accuracy due to our precise movement is guaranteed. A welded machine bed with a TRUMPF cutting bridge design ensures a good performance.



### **Strong service network**

The mGuard makes a remote service easy and safe. We can respond fast in every area thanks to our strong local service network and specialized technicians.





1 | Product Management 2D-Laser

## **Machine Layout**

### **Simple Ergonomic Layout**

- Clean and simple layout
- Easily accessible service areas
- Easy accessories layout







## **System Overview**




### **Laser Source:**

The TruFiber G series offers multimode fiber lasers with high beam quality of up to 12 kW of laser power and Bright Line mode laser variants up to 6 kW. Thanks to their broad power spectrum and special functions, they are an extremely cost-effective solution for precise cutting and welding applications



### TruFiber G modular architecture




#### **Cabinet**

- Designed with front/ rear/ top doors → service friendly for technicians
- IP54 rating → increased reliability

### **Control system (not TruControl!)**

- Flexible configuration
- Multi-interfaces, EtherCAT fieldbus configurable





Top view of control system

#### **High Power Combiner (HPC) & Beam Delivery Optic (BDO)**

- Fixed BDO, through splicing process replaceable in the field by TRUMPF service
- Integrated sensors and electronics for unique PierceLine and VariMode features

#### **Power supply**


- Modular design
- Power range from 2% 100% nominal power

### Up to 4 \* 3 kW laser modules

- Modular basis of new generation TruFiber
- Higher efficiency (optical to optical efficiency ≥78%,



## TruFiber G: Interfaces








## Cooling concept for TruFiber G

Requirements for chiller






**Coolant** 


DI-Water to be used.

Copper material is not allowed

in cooling system

## TruFiber G- Ergonomic layout








## TruFiber G

### Part Identifier



- EMERGENCY STOP 2. Signal lamp "Power On" push button
- 3. Indicator light "Fault"
- 4. Laser warning lamp
- 5. Reset push button
- 6. Key switch

7. Main switch




Fig. 4-3


The LCD display offers the following information:


- Product Name
- Serial Number
- MAC Address
- IP Address

With the IP address, the operator has the access to GUI.



## Electrical control interfaces





Control Interface Layout

For internal use
Interlock Interface
Digital Inputs
Digital Outputs
Analogue I/O
E-Stop Expanding

The inputs and outputs of interlock connections are voltage-free contacts on port X80.

The digital input circuit is designed to work with PLC signals on port X81, circuit type is sink input.

The digital outputs are PLC signals and supplied with 24 VDC from the laser on port X82, circuit type is source output.


Please make sure the voltage applied to X80, X81 and X82 will not exceed 30V DC.




Fig. 2-6

## TruFiber G - Safety circuit principle

The control unit of the laser device contains interfaces for safety circuits.








## TruFiber G - Operation with fieldbus

Apart from EtherNET, the laser device can also be controlled online via Fieldbus. The Fieldbus is an optional function. The module is located under top cover, on the laser control board. External connection is X2 port on rear door.






Fig. 3-11

Current available type of Fieldbus:

■ EtherCAT

For detailed information please see interface description: 90-17-00-000000-AS FieldBus Instruction



# TruFiber G - Cooling requirements

Parameter	Value			Notes
Output Power (kW)	3	6	12	
Maximum Cooling Capacity (kW) (Heat load to be removed from laser cabinet)	7.7	15.1	29.8	At end of life for nominal output power
Coolant Temperature (°C)	25 ± 2			Non condensing
Input pressure (bar)		6		Maximum for safe operation
Pressure Drop (bar)	2.5			Between inlet and outlet

Coolant Connection Diameter (mm)	25.4 (1")		32 (1.25")	Relative ID (inner diameter) hoses to be used		
Minimum flow rate (I/min)	28 55		107	At 25°C water temperature.		
Coolant Materials Compatibility	Aluminiur	n, stainles plastic	ss steel or	<ul> <li>DI-Water to be used.</li> <li>Copper material is not allowed in cooling system.</li> </ul>		
External Water Specification	Min		Max			
Appearance	Clear an	d without	sediment			
Particle size (µm)	-		100	100 mesh		
Electrical conductivity (µScm <sup>-1</sup> )	4		45	At 25°C		
рН	5.5		8.0			
Fiber Terminator Cooling Requirements						
Coolant Temperature (°C)	10 - 45			Non condensing		
Max. Water Pressure (bar)		8		Maximum for safe operation		
Coolant Connection Diameter (mm)	ID 4 OD 6			ID: Inner Diameter OD: Outer Diameter		
Flow rate (I/min)	1.5 – 3.0					



## **Accessory Overview- Chiller**



### Water Cooler (Chiller):


Laser Cutting Machine uses water chiller, Called the Eco cooler, to cool the components and ensure efficient operation.

The Eco Cooler circulates pure water through heat-generating components like the laser diodes, optics, drives, and control cabinets. The cooled components then return to the Eco Cooler, where they are cooled again by a heat exchanger.



# Tongfei coolers for TruLaser

Layout (example 3-6kW)







## **System Overview**



#### **Laser Suction:**

A suction system consisting of several suction chambers is present within the working range of the laser cutting machine. Each suction chamber is opened and closed using a pneumatically-operated flap and is connected to the central suction channel.

During the cutting operation, only the flap of the suction chamber below the cutting unit is opened.

The suction power is concentrated on only one chamber at a time, which ensures optimum suction of the fumes and airborne particles.



19 Anand | TruServices February 11, 2025 ■ Confidential